



Size	A	C	D	E	F nom	G nom	H+	J*	L
12	118	35	83	26	76	102	7	38	57
16	127	43	80	38	89	105	7	38	83
25	178	51	123	45	127	149	7	48	97
30	216	65	146	76	152	181	7	54	169
35	248	75	178	89	178	213	7	67	185
40	298	76	210	102	216	257	7	79	210
45	330	86	230	114	241	286	7	89	235
50	362	92	266	127	267	314	7	92	260

* is the wrench clearance to allow for tightening and loosening the bush on the shaft.

+ is the distance between shaft ends.