

4 Channel

DEA - TRANSMITTER



CODE TYPE

Smart button technology - each with pre-programmed buttons.

CHANNELS

4 available channels per programmed transmitter (all with smart button technology)

KIT CONTAINS

- 1 x transmitter
- 1 x 12 Volt Alkaline battery

HOW TO

Clearing All Transmitter Codes

1. Press and Hold the A and B Buttons until the LED light flashes 3 times.
2. Release the B button (but keep the A button pressed) and press the B button slowly 3 times and LED light with flash continuously on the third press.
3. Release the A button to finish code clearance



HOW TO

Copying Code from Original Transmitter

1. Hold the original remote and clone next to each other as possible.
2. Press and hold the button on the original remote you wish to copy, then press and hold the button on the clone remote you wish to use.
3. Keep holding both buttons until you see the LED light on the clone remote flash twice, three times and then stay on.
4. Release both buttons and test to see if it works with your motor.
5. Repeat steps 1-4 to copy other buttons.

WAREHOUSE